



Particle Board Screw Countersunk Zinc

3g

Size	Code	Phillips	Pozi
Pack Qty (if available)			
1/2	C0? 0312ZP	2000	
5/8	C0? 0316ZP	2000	
Driver Bit # 1			

4g

Size	Code	Phillips	Pozi
Pack Qty (if available)			
1/2	C0? 0412ZP	2000	2000
5/8	C0? 0416ZP	1000	1000
3/4	C0? 0420ZP	1000	1000
1"	C0? 0425ZP	1000	1000
Driver Bit # 1			

Replace ? With a 5 = Phillips or 6 = Pozi

5g

Size	Code	Phillips	Pozi
Pack Qty (if available)			
1/2	C0? 0512ZP	2000	2000
5/8	C0? 0516ZP	1000	1000
3/4	C0? 0520ZP	1000	1000
1"	C0? 0525ZP	1000	1000
Driver Bit # 2			

Replace ? With a 5 = Phillips or 6 = Pozi

6g

Size	Code	Phillips	Pozi
Pack Qty (if available)			
1/2	C0? 0612ZP	1000	1000
5/8	C0? 0616ZP	1000	1000
3/4	C0? 0620ZP	1000	1000
1"	C0? 0625ZP	1000	1000
1-1/4"	C0? 0632ZP	1000	1000
1-3/8"	C0? 0635ZP	1000	
1-1/2"	C0? 0638ZP	1000	1000
Driver Bit # 2			

Replace ? With a 5 = Phillips or 6 = Pozi





Particle Board Screw Countersunk Zinc

8g

Size	Code	Phillips	Pozi
		Pack Qty (if available)	
1/2	C0? 0812ZP	1000	1000
5/8	C0? 0816ZP	1000	1000
3/4	C0? 0820ZP	1000	1000
1"	C0? 0825ZP	1000	1000
1-1/8"	C0? 0828ZP	1000	1000
1-1/4"	C0? 0832ZP	1000	1000
1-3/8"	C0? 0835ZP	1000	1000
1-1/2"	C0? 0838ZP	1000	1000
1-5/8"	C0? 0841P	1000	
1-3/4"	C0? 0845ZP	1000	1000
2"	C0? 0850ZP	500	500
2-1/8"	C0? 0853ZP	500	500
2-3/8"	C0? 0860ZP	500	500



Driver Bit # 2

Replace ? With a 5 = Phillips or 6 = Pozi

10g

Size	Code	Phillips	Pozi
		Pack Qty (if available)	
3/4	C0? 1020ZP	1000	1000
1"	C0? 1025ZP	1000	1000
1-1/4"	C0? 1032ZP	1000	1000
1-1/2"	C0? 1038ZP	1000	1000
1-5/8"	C0? 1041ZP	1000	1000
1-3/4"	C0? 1045ZP	1000	1000
2"	C0? 1050ZP	1000	1000
2-1/8"	C0? 1053ZP	1000	1000
2-3/8"	C0? 1060ZP	1000	
2-1/2"	C0? 1063ZP	1000	1000
70mm	C0? 1070ZP	500	
75mm	C0? 1075ZP	500	500
80mm	C0? 1080ZP	200	
85mm	C0? 1085ZP	200	
90mm	C0? 1090ZP	200	

Driver Bit # 2

Replace ? With a 5 = Phillips or 6 = Pozi



Particle Board Screw Countersunk Phillips Decorative Plating Finishes

3g

Size	Code	Electro Brass	Florentine Bronze	Black
Pack Qty (if available)				
1/2	C05 0312??	2000		2000
5/8	C05 0316??	2000	2000	2000
Driver Bit # 1				
Replace ?? With EB = Electro Brass, FB = Florentine Bronze or BL = Black				



4g

Size	Code	Electro Brass	Florentine Bronze	Black
Pack Qty (if available)				
1/2	C05 0412??	2000		2000
5/8	C05 0416??	1000	1000	2000
Driver Bit # 1				
Replace ?? With EB = Electro Brass, FB = Florentine Bronze or BL = Black				

5g

Size	Code	Electro Brass	Florentine Bronze	Black
Pack Qty (if available)				
1/2	C05 0512??	2000		2000
5/8	C05 0516??	1000	1000	1000
Driver Bit # 2				
Replace ?? With EB = Electro Brass, FB = Florentine Bronze or BL = Black				

6g

Size	Code	Electro Brass	Florentine Bronze	Black
Pack Qty (if available)				
1/2	C05 0612??	2000		2000
5/8	C05 0616??		1000	1000
Driver Bit # 2				
Replace ?? With EB = Electro Brass, FB = Florentine Bronze or BL = Black				