



Chipboard Screw Countersunk Phillips S.E.H.

8g

Code	Length	Zinc Yellow	Class 3	Pack Qty (if available)
C00 08016??	16mm			1000
C00 08019??	19mm			1000
C00 08020??	20mm		1000	1000
C00 08022??	22mm		1000	1000
C00 08025??	25mm		1000	1000
C00 08028??	28mm		1000	1000
C00 08030??	30mm		1000	1000
C00 08032??	32mm		1000	1000
C00 08035??	35mm		1000	1000
C00 08038??	38mm			1000
C00 08040??	40mm		1000	1000
C00 08045??	45mm		1000	1000
C00 08050??	50mm		1000	1000
C00 08057??	57mm		1000	1000
C00 08065??	65mm		1000	1000



Driver Bit # 2

Replace ?? With ZY = Zinc Yellow or C3 = Class 3

10g

Code	Length	Zinc Yellow	Class 3	Pack Qty (if available)
C00 10040??	40mm			1000
C00 10050??	50mm			1000
C00 10065??	65mm		1000	1000
C00 10075??	75mm		1000	1000
C00 10100??	100mm		250	250
C00 10125??	125mm		250	250
C00 10150??	150mm			250

Driver Bit # 2

Replace ?? With ZY = Zinc Yellow or C3 = Class 3



Chipboard Screw Countersunk S.E.H. Square Drive

8g

Code	Length	Zinc Yellow	Class 3	Pack Qty (if available)
C01 08020??	20mm	1000	1000	
C01 08025??	25mm	1000	1000	
C01 08028??	28mm	1000	1000	
C01 08032??	32mm	1000	1000	
C01 08035??	35mm	1000	1000	
C01 08038??	38mm	1000	1000	
C01 08040??	40mm	1000	1000	
C01 08045??	45mm	1000	1000	
C01 08050??	50mm	1000	1000	
C01 08057??	57mm	1000	1000	
C01 08065??	65mm	1000	1000	



Driver Bit # 2

Replace ?? With ZY = Zinc Yellow or C3 = Class 3

10g

Code	Length	Zinc Yellow	Class 3	Pack Qty (if available)
C01 10065??	65mm	500	500	
C01 10075??	75mm	1000	500	
C01 10100??	100mm		250	
C01 10125??	125mm		250	

Driver Bit # 2

Replace ?? With ZY = Zinc Yellow or C3 = Class 3