



Button Head Socket Screw - Metric - Gr 10.9

M3 x 0.5 p

| Length | Code | Plain | Zinc |
|------------------------------|-------------|-------|------|
| Pack Quantity (if available) | | | |
| 5mm | U27 03005?? | 100 | 100 |
| 6mm | U27 03006?? | 100 | 100 |
| 8mm | U27 03008?? | 100 | 100 |
| 10mm | U27 03010?? | 100 | 100 |
| 12mm | U27 03012?? | 100 | 100 |
| 16mm | U27 03016?? | 100 | 100 |
| 20mm | U27 03020?? | 100 | 100 |
| 25mm | U27 03025?? | 100 | 100 |
| 30mm | U27 03030?? | 100 | 100 |



Wrench size 2.0mm

Replace ?? With PL = Plain or ZP = Zinc

M4 x 0.7 p

| Length | Code | Plain | Zinc |
|------------------------------|-------------|-------|------|
| Pack Quantity (if available) | | | |
| 6mm | U27 04006?? | 100 | 100 |
| 8mm | U27 04008?? | 100 | 100 |
| 10mm | U27 04010?? | 100 | 100 |
| 12mm | U27 04012?? | 100 | 100 |
| 16mm | U27 04016?? | 100 | 100 |
| 20mm | U27 04020?? | 100 | 100 |
| 25mm | U27 04025?? | 100 | 100 |
| 30mm | U27 04030?? | 100 | 100 |
| 35mm | U27 04035?? | 100 | 100 |
| 40mm | U27 04040?? | 100 | 100 |
| 45mm | U27 04045?? | 100 | 100 |
| 50mm | U27 04050?? | 100 | 100 |

Wrench size 2.5mm

Replace ?? With PL = Plain or ZP = Zinc

M5 x 0.8 p

| Length | Code | Plain | Zinc |
|------------------------------|-------------|-------|------|
| Pack Quantity (if available) | | | |
| 6mm | U27 05006?? | 100 | 100 |
| 8mm | U27 05008?? | 100 | 100 |
| 10mm | U27 05010?? | 100 | 100 |
| 12mm | U27 05012?? | 100 | 100 |
| 16mm | U27 05016?? | 100 | 100 |
| 20mm | U27 05020?? | 100 | 100 |
| 25mm | U27 05025?? | 100 | 100 |

Wrench size 3.0mm

Replace ?? With PL = Plain or ZP = Zinc

Continued next page



Button Head Socket Screw - Metric - Gr 10.9

Continued from previous page

M5 x 0.8 p

| Length | Code | Plain | Zinc |
|--------|-------------|------------------------------|------|
| | | Pack Quantity (if available) | |
| 30mm | U27 05030?? | 100 | 100 |
| 35mm | U27 05035?? | 100 | 100 |
| 40mm | U27 05040?? | 100 | 100 |
| 45mm | U27 05045?? | 100 | 100 |
| 50mm | U27 05050?? | 100 | 100 |
| 55mm | U27 05055?? | 100 | 100 |
| 60mm | U27 05060?? | 100 | 100 |
| 65mm | U27 05065?? | 100 | |
| 70mm | U27 05070?? | 100 | |
| 80mm | U27 05080?? | 100 | |



Wrench size 3.0mm

Replace ?? With PL = Plain or ZP = Zinc

M6 x 1.0 p

| Length | Code | Plain | Zinc |
|--------|-------------|------------------------------|------|
| | | Pack Quantity (if available) | |
| 8mm | U27 06008?? | 100 | 100 |
| 10mm | U27 06010?? | 100 | 100 |
| 12mm | U27 06012?? | 100 | 100 |
| 16mm | U27 06016?? | 100 | 100 |
| 20mm | U27 06020?? | 100 | 100 |
| 25mm | U27 06025?? | 100 | 100 |
| 30mm | U27 06030?? | 100 | 100 |
| 35mm | U27 06035?? | 100 | 100 |
| 40mm | U27 06040?? | 100 | 100 |
| 45mm | U27 06045?? | 100 | 100 |
| 50mm | U27 06050?? | 100 | 100 |
| 60mm | U27 06060?? | 100 | 100 |
| 65mm | U27 06065?? | 100 | 100 |
| 70mm | U27 06070?? | 100 | 100 |
| 75mm | U27 06075?? | 100 | 100 |
| 80mm | U27 06080?? | 100 | 100 |

Wrench size 4.0mm

Replace ?? With PL = Plain or ZP = Zinc

M8 x 1.25 p

| Length | Code | Plain | Zinc |
|--------|-------------|------------------------------|------|
| | | Pack Quantity (if available) | |
| 10mm | U27 08010?? | 100 | 100 |
| 12mm | U27 08012?? | 100 | 100 |

Wrench size 5.0mm

Replace ?? With PL = Plain or ZP = Zinc

Continued next page



Button Head Socket Screw - Metric - Gr 10.9

Continued from previous page

M8 x 1.25 p

| Length | Code | Plain | Zinc |
|-------------------|-------------|---|------|
| | | Pack Quantity (if available) | |
| 16mm | U27 08016?? | 100 | 100 |
| 20mm | U27 08020?? | 100 | 100 |
| 25mm | U27 08025?? | 100 | 100 |
| 30mm | U27 08030?? | 100 | 100 |
| 35mm | U27 08035?? | 100 | 100 |
| 40mm | U27 08040?? | 100 | 100 |
| 45mm | U27 08045?? | 100 | 100 |
| 50mm | U27 08050?? | 100 | 100 |
| 55mm | U27 08055?? | 100 | 100 |
| 60mm | U27 08060?? | 100 | 100 |
| 70mm | U27 08070?? | 100 | 100 |
| 75mm | U27 08075?? | 100 | 100 |
| 80mm | U27 08080?? | 100 | 100 |
| 100mm | U27 08100?? | 100 | 100 |
| Wrench size 5.0mm | | Replace ?? With PL = Plain or ZP = Zinc | |



M10 x 1.5 p

| Length | Code | Plain | Zinc |
|-------------------|-------------|---|------|
| | | Pack Quantity (if available) | |
| 12mm | U27 10012?? | 100 | 100 |
| 16mm | U27 10016?? | 100 | 100 |
| 20mm | U27 10020?? | 100 | 100 |
| 25mm | U27 10025?? | 100 | 100 |
| 30mm | U27 10030?? | 100 | 100 |
| 35mm | U27 10035?? | 100 | 100 |
| 40mm | U27 10040?? | 100 | 100 |
| 45mm | U27 10045?? | 100 | 100 |
| 50mm | U27 10050?? | 100 | 100 |
| 55mm | U27 10055?? | 100 | 100 |
| 60mm | U27 10060?? | 100 | 100 |
| 70mm | U27 10070?? | 100 | 100 |
| 80mm | U27 10080?? | 50 | 50 |
| 90mm | U27 10090?? | 50 | 50 |
| 100mm | U27 10100?? | 50 | 50 |
| Wrench size 6.0mm | | Replace ?? With PL = Plain or ZP = Zinc | |



Button Head Socket Screw - Metric - Gr 10.9

M12 x 1.75 p

| Length | Code | Plain | Zinc |
|------------------------------|-------------|-------|------|
| Pack Quantity (if available) | | | |
| 16mm | U27 12016?? | 100 | 100 |
| 20mm | U27 12020?? | 100 | 100 |
| 25mm | U27 12025?? | 100 | 100 |
| 30mm | U27 12030?? | 100 | 100 |
| 35mm | U27 12035?? | 100 | 100 |
| 40mm | U27 12040?? | 100 | 100 |
| 45mm | U27 12045?? | 100 | 100 |
| 50mm | U27 12050?? | 100 | 100 |
| 60mm | U27 12060?? | 50 | 50 |
| 70mm | U27 12070?? | 50 | 50 |
| 80mm | U27 12080?? | 50 | 50 |
| 90mm | U27 12090?? | 50 | 50 |
| 100mm | U27 12100?? | 50 | 50 |



Wrench size 8.0mm

Replace ?? With PL = Plain or ZP = Zinc

M16 x 2.0 p

| Length | Code | Plain | Zinc |
|------------------------------|-------------|-------|------|
| Pack Quantity (if available) | | | |
| 50mm | U27 16050?? | 50 | 50 |
| 60mm | U27 16060?? | 50 | 50 |
| 70mm | U27 16070?? | 25 | 25 |
| 80mm | U27 16080?? | 25 | 25 |
| 90mm | U27 16090?? | 25 | 25 |
| 100mm | U27 16100?? | 25 | 25 |

Wrench size 10.0mm

Replace ?? With PL = Plain or ZP = Zinc