



## Flat Head Socket Screw - Metric - Gr 12.9

### M3 x 0.5 p

Length	Code	Plain	Zinc
Pack Quantity (if available)			
5mm	U18 03005??	100	100
6mm	U18 03006??	100	100
8mm	U18 03008??	100	100
10mm	U18 03010??	100	100
12mm	U18 03012??	100	100
16mm	U18 03016??	100	100
20mm	U18 03020??	100	100
25mm	U18 03025??	100	100
30mm	U18 03030??	100	100
35mm	U18 03035??	100	100
40mm	U18 03040??	100	100
45mm	U18 03045??	100	100
50mm	U18 03050??	100	100



Wrench size 2.0mm

Replace ?? With PL = Plain or ZP = Zinc

### M4 x 0.7 p

Length	Code	Plain	Zinc
Pack Quantity (if available)			
6mm	U18 04006??	100	100
8mm	U18 04008??	100	100
10mm	U18 04010??	100	100
12mm	U18 04012??	100	100
16mm	U18 04016??	100	100
20mm	U18 04020??	100	100
25mm	U18 04025??	100	100
30mm	U18 04030??	100	100
35mm	U18 04035??	100	100
40mm	U18 04040??	100	100
45mm	U18 04045??	100	100
50mm	U18 04050??	100	100
55mm	U18 04055??	100	100
60mm	U18 04060??	100	100
70mm	U18 04070??	100	100

Wrench size 2.5mm

Replace ?? With PL = Plain or ZP = Zinc

### M5 x 0.8 p

Length	Code	Plain	Zinc
Pack Quantity (if available)			
6mm	U18 05006??	100	100

Wrench size 3.0mm

Replace ?? With PL = Plain or ZP = Zinc

Continued next page



## Flat Head Socket Screw - Metric - Gr 12.9

Continued from previous page

### M5 x 0.8 p

Length	Code	Plain	Zinc
		Pack Quantity (if available)	
8mm	U18 05008??	100	100
10mm	U18 05010??	100	100
12mm	U18 05012??	100	100
16mm	U18 05016??	100	100
20mm	U18 05020??	100	100
25mm	U18 05025??	100	100
30mm	U18 05030??	100	100
35mm	U18 05035??	100	100
40mm	U18 05040??	100	100
45mm	U18 05045??	100	100
50mm	U18 05050??	100	100
55mm	U18 05055??	100	100
60mm	U18 05060??	100	100
65mm	U18 05065??	100	
70mm	U18 05070??	100	
80mm	U18 05080??	100	
Wrench size 3.0mm		Replace ?? With PL = Plain or ZP = Zinc	



### M6 x 1.0 p

Length	Code	Plain	Zinc
		Pack Quantity (if available)	
8mm	U18 06008??	100	100
10mm	U18 06010??	100	100
12mm	U18 06012??	100	100
16mm	U18 06016??	100	100
20mm	U18 06020??	100	100
25mm	U18 06025??	100	100
30mm	U18 06030??	100	100
35mm	U18 06035??	100	100
40mm	U18 06040??	100	100
45mm	U18 06045??	100	100
50mm	U18 06050??	100	100
55mm	U18 06055??	100	100
60mm	U18 06060??	100	100
65mm	U18 06065??	100	100
70mm	U18 06070??	100	100
75mm	U18 06075??	100	100
80mm	U18 06080??	100	100
Wrench size 4.0mm		Replace ?? With PL = Plain or ZP = Zinc	

Continued next page



## Flat Head Socket Screw - Metric - Gr 12.9

Continued from previous page

### M6 x 1.0 p

Length	Code	Plain	Zinc
		Pack Quantity (if available)	
90mm	U18 06090??		
100mm	U18 06100??	100	100
Wrench size 4.0mm		Replace ?? With PL = Plain or ZP = Zinc	



### M8 x 1.25 p

Length	Code	Plain	Zinc
		Pack Quantity (if available)	
10mm	U18 08010??	100	100
12mm	U18 08012??	100	100
16mm	U18 08016??	100	100
20mm	U18 08020??	100	100
25mm	U18 08025??	100	100
30mm	U18 08030??	100	100
35mm	U18 08035??	100	100
40mm	U18 08040??	100	100
45mm	U18 08045??	100	100
50mm	U18 08050??	100	100
55mm	U18 08055??	100	100
60mm	U18 08060??	100	100
70mm	U18 08070??	100	100
75mm	U18 08075??		100
80mm	U18 08080??	100	100
90mm	U18 08090??	100	100
100mm	U18 08100??	100	100
110mm	U18 08110??	100	100
120mm	U18 08120??	100	100
Wrench size 5.0mm		Replace ?? With PL = Plain or ZP = Zinc	

### M10 x 1.5 p

Length	Code	Plain	Zinc
		Pack Quantity (if available)	
12mm	U18 10012??	100	100
16mm	U18 10016??	100	100
20mm	U18 10020??	100	100
25mm	U18 10025??	100	100
30mm	U18 10030??	100	100
35mm	U18 10035??	100	100
40mm	U18 10040??	100	100
Wrench size 6.0mm		Replace ?? With PL = Plain or ZP = Zinc	

Continued next page



## Flat Head Socket Screw - Metric - Gr 12.9

Continued from previous page

### M10 x 1.5 p

Length	Code	Plain	Zinc
		Pack Quantity (if available)	
45mm	U18 10045??	100	100
50mm	U18 10050??	100	100
55mm	U18 10055??	100	100
60mm	U18 10060??	100	100
70mm	U18 10070??	100	100
75mm	U18 10075??	100	100
80mm	U18 10080??	50	50
90mm	U18 10090??	50	50
100mm	U18 10100??	50	50
110mm	U18 10110??	50	50
120mm	U18 10120??	50	50
130mm	U18 10130??	50	50



Wrench size 6.0mm

Replace ?? With PL = Plain or ZP = Zinc

### M12 x 1.75 p

Length	Code	Plain	Zinc
		Pack Quantity (if available)	
20mm	U18 12020??	100	100
25mm	U18 12025??	100	100
30mm	U18 12030??	100	100
35mm	U18 12035??	100	100
40mm	U18 12040??	100	100
45mm	U18 12045??	100	100
50mm	U18 12050??	100	100
55mm	U18 12055??	50	50
60mm	U18 12060??	50	50
70mm	U18 12070??	50	50
80mm	U18 12080??	50	50
90mm	U18 12090??	50	50
100mm	U18 12100??	50	50
110mm	U18 12110??	50	50
120mm	U18 12120??	50	50
130mm	U18 12130??	50	50
140mm	U18 12140??	50	50
150mm	U18 12150??	50	50
180mm	U18 12180??	50	50
200mm	U18 12200??	50	50
220mm	U18 12220??	50	50
250mm	U18 12250??	50	50

Wrench size 8.0mm

Replace ?? With PL = Plain or ZP = Zinc



## Flat Head Socket Screw - Metric - Gr 12.9

### M14 x 2.0 p

Length	Code	Plain	Zinc
Pack Quantity (if available)			
25mm	U18 14025??	50	50
30mm	U18 14030??	50	50
35mm	U18 14035??	50	50
40mm	U18 14040??	50	50
45mm	U18 14045??	50	50
50mm	U18 14050??	50	50
55mm	U18 14055??	50	50
60mm	U18 14060??	50	50
65mm	U18 14065??	25	25
70mm	U18 14070??	25	25
80mm	U18 14080??	25	25
90mm	U18 14090??	25	25
100mm	U18 14100??	25	25



Wrench size 10.0mm

Replace ?? With PL = Plain or ZP = Zinc

### M16 x 2.0 p

Length	Code	Plain	Zinc
Pack Quantity (if available)			
20mm	U18 16020??	50	50
25mm	U18 16025??	50	50
30mm	U18 16030??	50	50
35mm	U18 16035??	50	50
40mm	U18 16040??	50	50
45mm	U18 16045??	50	50
50mm	U18 16050??	50	50
55mm	U18 16055??	50	50
60mm	U18 16060??	50	50
65mm	U18 16065??	50	50
70mm	U18 16070??	25	25
75mm	U18 16075??	25	25
80mm	U18 16080??	25	25
90mm	U18 16090??	25	25
100mm	U18 16100??	25	25
110mm	U18 16110??	25	25
120mm	U18 16120??	25	25
130mm	U18 16130??	25	25
140mm	U18 16140??	25	25
150mm	U18 16150??	25	25
160mm	U18 16160??	25	25

Wrench size 10.0mm

Replace ?? With PL = Plain or ZP = Zinc

Continued next page



## Flat Head Socket Screw - Metric - Gr 12.9

Continued from previous page

### M16 x 2.0 p

Length	Code	Plain	Zinc
		Pack Quantity (if available)	
180mm	U18 16180??	25	25
200mm	U18 16200??	25	25
220mm	U18 16220??	25	25
240mm	U18 16240??	25	25
Wrench size 10.0mm		Replace ?? With PL = Plain or ZP = Zinc	



### M20 x 2.5 p

Length	Code	Plain	Zinc
		Pack Quantity (if available)	
35mm	U18 20035??	25	25
40mm	U18 20040??	25	25
45mm	U18 20045??	25	25
50mm	U18 20050??	25	25
55mm	U18 20055??	25	25
60mm	U18 20060??	25	25
70mm	U18 20070??	25	25
75mm	U18 20075??	25	25
80mm	U18 20080??	25	25
90mm	U18 20090??	25	25
100mm	U18 20100??	25	25
110mm	U18 20110??	25	25
120mm	U18 20120??	10	10
130mm	U18 20130??	10	10
140mm	U18 20140??	10	10
150mm	U18 20150??	10	10
160mm	U180 20160??	10	10
180mm	U18 20180??	10	10
200mm	U18 20200??	10	10
220mm	U18 20220??	10	10
240mm	U18 20240??	10	10
Wrench size 12.0mm		Replace ?? With PL = Plain or ZP = Zinc	

### M24 x 3.0 p

Length	Code	Plain	Zinc
		Pack Quantity (if available)	
50mm	U18 24050??	10	10
60mm	U18 24060??	10	10
70mm	U18 24070??	10	10
Wrench size 14.0mm		Replace ?? With PL = Plain or ZP = Zinc	

Continued next page



## Flat Head Socket Screw - Metric - Gr 12.9

Continued from previous page

### M24 x 3.0 p

Length	Code	Pack Quantity (if available)	
		Plain	Zinc
80mm	U18 24080??	10	10
90mm	U18 24090??	10	10
100mm	U18 24100??	10	10
110mm	U18 24110??	10	10
120mm	U18 24120??	10	10
130mm	U18 24130??	10	10
140mm	U18 24140??	10	10
150mm	U18 24150??	10	10
160mm	U18 24160??	10	10
180mm	U18 24180??	10	10
200mm	U18 24200??	10	10
220mm	U18 24220??	10	10
240mm	U18 24240??	10	10
300mm	U18 24300??	10	10
Wrench size 14.0mm		Replace ?? With PL = Plain or ZP = Zinc	

