



Pan Head Machine Screw - Imperial - Stainless

3/16 Bsw (Phillips)

Size	Code	Gr 304 / A2	Gr 316 / A4
Pack Quantity (if available)			
1/4	X36 0506PP???	100	
3/8	X36 0510PP???	100	
1/2	X36 0512PP???	100	100
5/8	X36 0516PP???	100	
3/4	X36 0520PP???	100	100
1"	X36 0525PP???	100	100
1-1/4"	X36 0532PP???	100	100
1-1/2"	X36 0538PP???	100	100
1-3/4"	X36 0545PP???	100	
2"	X36 0550PP???	100	100
2-1/2"	X36 0563PP???	100	100
3"	X36 0575PP???	100	100
Replace ??? With 304 or 316			



1/4 Bsw (Phillips)

Size	Code	Gr 304 / A2	Gr 316 / A4
Pack Quantity (if available)			
3/8	X36 0610PP???	100	
1/2	X36 0612PP???	100	
5/8	X36 0616PP???	100	
3/4	X36 0620PP???	100	100
1"	X36 0625PP???	100	100
1-1/4"	X36 0632PP???	100	100
1-1/2"	X36 0638PP???	100	100
1-3/4"	X36 0645PP???	100	
2"	X36 0650PP???	100	100
2-1/2"	X36 0663PP???	50	
3"	X36 0675PP???	50	50
4"	X36 0699PP???	50	
Replace ??? With 304 or 316			

5/16 Bsw (Phillips)

Size	Code	Gr 304 / A2	Gr 316 / A4
Pack Quantity (if available)			
3/4	X36 0820PP???	100	100
1"	X36 0825PP???	100	100
1-1/4"	X36 0832PP???		100
1-1/2"	X36 0838PP???	100	100
Replace ??? With 304 or 316			

Continued next page



Pan Head Machine Screw - Imperial - Stainless

Continued from previous page

5/16 Bsw (Phillips)

Size	Code	Gr 304 / A2	Gr 316 / A4
		Pack Quantity (if available)	
1-3/4"	X36 0845PP???	100	100
2"	X36 0850PP???	100	100
2-1/2"	X36 0863PP???	100	
3"	X36 0875PP???	100	100
Replace ??? With 304 or 316			

