



Round Head Machine Screw - Imperial - Stainless

5/32 Bsw (Slot)

Size	Code	Gr 304 / A2	Gr 316 / A4
Pack Quantity (if available)			
1/4	X36 0406RS304	100	
3/8	X36 0410RS304	100	
1/2	X36 0412RS304	100	
5/8	X36 0416RS304	100	
3/4	X36 0420RS304	100	
1"	X36 0425RS304	100	
1-1/4"	X36 0432RS304	100	
1-1/2"	X36 0438RS304	100	
2"	X36 0450RS304	100	



3/16 Bsw (Slot)

Size	Code	Gr 304 / A2	Gr 316 / A4
Pack Quantity (if available)			
1/4	X36 0506RS???	100	100
3/8	X36 0510RS???	100	100
1/2	X36 0512RS???	100	100
5/8	X36 0516RS???	100	100
3/4	X36 0520RS???	100	100
1"	X36 0525RS???	100	100
1-1/4"	X36 0532RS???	100	100
1-1/2"	X36 0538RS???	100	100
1-3/4"	X36 0545RS???	100	
2"	X36 0550RS???	100	100
2-1/2"	X36 0563RS???	100	100
3"	X36 0575RS???	100	100
Replace ??? With 304 or 316			

1/4 Bsw (Slot)

Size	Code	Gr 304 / A2	Gr 316 / A4
Pack Quantity (if available)			
3/8	X36 0610RS???	100	
1/2	X36 0612RS???	100	100
5/8	X36 0616RS???	100	100
3/4	X36 0620RS???	100	100
1"	X36 0625RS???	100	100
1-1/4"	X36 0632RS???	100	100
1-1/2"	X36 0638RS???	100	100
1-3/4"	X36 0645RS???	100	
Replace ??? With 304 or 316			

Continued next page



Round Head Machine Screw - Imperial - Stainless

Continued from previous page

1/4 Bsw (Slot)

Size	Code	Gr 304 / A2	Gr 316 / A4
Pack Quantity (if available)			
2"	X36 0650RS???	100	100
2-1/4"	X36 0657RS???	50	
2-1/2"	X36 0663RS???	50	50
3"	X36 0675RS???	50	50
4"	X36 0699RS???	50	50



Replace ??? With 304 or 316

5/16 Bsw (Slot)

Size	Code	Gr 304 / A2	Gr 316 / A4
Pack Quantity (if available)			
1/2	X36 0812RS???	100	
5/8	X36 0816RS???	100	
3/4	X36 0820RS???	100	100
1"	X36 0825RS???	100	100
1-1/4"	X36 0832RS???	100	100
1-1/2"	X36 0838RS???	100	100
1-3/4"	X36 0845RS???	100	
2"	X36 0850RS???	100	
2-1/2"	X36 0863RS???	50	50
3"	X36 0875RS???	50	50
4"	X36 0899RS???	50	

Replace ??? With 304 or 316