



Round Head Machine Screw - Imperial - Stainless

5/32 Bsw (Slot)

Code	Length	Gr 304 / A2	Pack Quantity (if available)
X36 0406RS304	1/4	100	100
X36 0410RS304	3/8	100	100
X36 0412RS304	1/2	100	100
X36 0416RS304	5/8	100	100
X36 0420RS304	3/4	100	100
X36 0425RS304	1"	100	100
X36 0432RS304	1-1/4"	100	100
X36 0438RS304	1-1/2"	100	100
X36 0450RS304	2"	100	100



3/16 Bsw (Slot)

Code	Length	Gr 304 / A2	Gr 316 / A4
X36 0506RS???	1/4	100	100
X36 0510RS???	3/8	100	100
X36 0512RS???	1/2	100	100
X36 0516RS???	5/8	100	100
X36 0520RS???	3/4	100	100
X36 0525RS???	1"	100	100
X36 0532RS???	1-1/4"	100	100
X36 0538RS???	1-1/2"	100	100
X36 0545RS???	1-3/4"	100	
X36 0550RS???	2"	100	100
X36 0563RS???	2-1/2"	100	100
X36 0575RS???	3"	100	100
Replace ??? With 304 or 316			

1/4 Bsw (Slot)

Length	Code	Gr 304 / A2	Gr 316 / A4
3/8	X36 0610RS???	100	
1/2	X36 0612RS???	100	100
5/8	X36 0616RS???	100	100
3/4	X36 0620RS???	100	100
1"	X36 0625RS???	100	100
1-1/4"	X36 0632RS???	100	100
1-1/2"	X36 0638RS???	100	100
1-3/4"	X36 0645RS???	100	
2"	X36 0650RS???	100	100
2-1/4"	X36 0657RS???	50	



Continued next page



Continued from previous page

2-1/2"	X36 0663RS???	50	50
3"	X36 0675RS???	50	50
4"	X36 0699RS???	50	50

Replace ??? With 304 or 316

5/16 Bsw (Slot)

Code	Length	Gr 304 / A2	Gr 316 / A4
Pack Quantity (if available)			
X36 0812RS???	1/2	100	
X36 0816RS???	5/8	100	
X36 0820RS???	3/4	100	100
X36 0825RS???	1"	100	100
X36 0832RS???	1-1/4"	100	100
X36 0838RS???	1-1/2"	100	100
X36 0845RS???	1-3/4"	100	
X36 0850RS???	2"	100	
X36 0863RS???	2-1/2"	50	50
X36 0875RS???	3"	50	50
X36 0899RS???	4"	50	



Replace ??? With 304 or 316