



## Button Head Socket Screw - Metric - Gr 10.9

### M3 x 0.5 p

Code	Length	Plain	Zinc
<b>Pack Quantity (if available)</b>			
U27 03005??	5mm	100	100
U27 03006??	6mm	100	100
U27 03008??	8mm	100	100
U27 03010??	10mm	100	100
U27 03012??	12mm	100	100
U27 03016??	16mm	100	100
U27 03020??	20mm	100	100
U27 03025??	25mm	100	100
U27 03030??	30mm	100	100



Wrench size 2.0mm

Replace ?? With PL = Plain or ZP = Zinc

### M4 x 0.7 p

Code	Length	Plain	Zinc
<b>Pack Quantity (if available)</b>			
U27 04006??	6mm	100	100
U27 04008??	8mm	100	100
U27 04010??	10mm	100	100
U27 04012??	12mm	100	100
U27 04016??	16mm	100	100
U27 04020??	20mm	100	100
U27 04025??	25mm	100	100
U27 04030??	30mm	100	100
U27 04035??	35mm	100	100
U27 04040??	40mm	100	100
U27 04045??	45mm	100	100
U27 04050??	50mm	100	100

Wrench size 2.5mm

Replace ?? With PL = Plain or ZP = Zinc

### M5 x 0.8 p

Code	Length	Plain	Zinc
<b>Pack Quantity (if available)</b>			
U27 05006??	6mm	100	100
U27 05008??	8mm	100	100
U27 05010??	10mm	100	100
U27 05012??	12mm	100	100
U27 05016??	16mm	100	100
U27 05020??	20mm	100	100
U27 05025??	25mm	100	100
U27 05030??	30mm	100	100
U27 05035??	35mm	100	100



Continued next page



Continued from previous page

Code	Length	Plain	Zinc
U27 05040??	40mm	100	100
U27 05045??	45mm	100	100
U27 05050??	50mm	100	100
U27 05055??	55mm	100	100
U27 05060??	60mm	100	100
U27 05065??	65mm	100	
U27 05070??	70mm	100	
U27 05080??	80mm	100	
Wrench size 3.0mm		Replace ?? With PL = Plain or ZP = Zinc	



**M6 x 1.0 p**

Code	Length	Plain	Zinc
<b>Pack Quantity (if available)</b>			
U27 06008??	8mm	100	100
U27 06010??	10mm	100	100
U27 06012??	12mm	100	100
U27 06016??	16mm	100	100
U27 06020??	20mm	100	100
U27 06025??	25mm	100	100
U27 06030??	30mm	100	100
U27 06035??	35mm	100	100
U27 06040??	40mm	100	100
U27 06045??	45mm	100	100
U27 06050??	50mm	100	100
U27 06060??	60mm	100	100
U27 06065??	65mm	100	100
U27 06070??	70mm	100	100
U27 06075??	75mm	100	100
U27 06080??	80mm	100	100
Wrench size 4.0mm		Replace ?? With PL = Plain or ZP = Zinc	

**M8 x 1.25 p**

Code	Length	Plain	Zinc
<b>Pack Quantity (if available)</b>			
U27 08010??	10mm	100	100
U27 08012??	12mm	100	100
U27 08016??	16mm	100	100
U27 08020??	20mm	100	100
U27 08025??	25mm	100	100
U27 08030??	30mm	100	100
U27 08035??	35mm	100	100
U27 08040??	40mm	100	100
U27 08045??	45mm	100	100



Continued next page



Continued from previous page

U27 08050??	50mm	100	100
U27 08055??	55mm	100	100
U27 08060??	60mm	100	100
U27 08070??	70mm	100	100
U27 08075??	75mm	100	100
U27 08080??	80mm	100	100
U27 08100??	100mm	100	100

Wrench size 5.0mm

Replace ?? With PL = Plain or ZP = Zinc

**M10 x 1.5 p**

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U27 10012??	12mm	100	100
U27 10016??	16mm	100	100
U27 10020??	20mm	100	100
U27 10025??	25mm	100	100
U27 10030??	30mm	100	100
U27 10035??	35mm	100	100
U27 10040??	40mm	100	100
U27 10045??	45mm	100	100
U27 10050??	50mm	100	100
U27 10055??	55mm	100	100
U27 10060??	60mm	100	100
U27 10070??	70mm	100	100
U27 10080??	80mm	50	50
U27 10090??	90mm	50	50
U27 10100??	100mm	50	50



Wrench size 6.0mm

Replace ?? With PL = Plain or ZP = Zinc

**M12 x 1.75 p**

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U27 12016??	16mm	100	100
U27 12020??	20mm	100	100
U27 12025??	25mm	100	100
U27 12030??	30mm	100	100
U27 12035??	35mm	100	100
U27 12040??	40mm	100	100
U27 12045??	45mm	100	100
U27 12050??	50mm	100	100
U27 12060??	60mm	50	50
U27 12070??	70mm	50	50
U27 12080??	80mm	50	50



Continued next page



Continued from previous page

U27 12090??	90mm	50	50
U27 12100??	100mm	50	50
Wrench size 8.0mm		Replace ?? With PL = Plain or ZP = Zinc	

**M16 x 2.0 p**

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U27 16050??	50mm	50	50
U27 16060??	60mm	50	50
U27 16070??	70mm	25	25
U27 16080??	80mm	25	25
U27 16090??	90mm	25	25
U27 16100??	100mm	25	25
Wrench size 10.0mm		Replace ?? With PL = Plain or ZP = Zinc	

