



UNF Socket Head Cap Screw - Alloy Steel

#10 Unf - 32 tpi

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U03 05008??	5/16	100	100
U03 05010??	3/8	100	100
U03 05012??	1/2	100	100
U03 05016??	5/8	100	100
U03 05020??	3/4	100	100
U03 05025??	1"	100	100
U03 05032??	1-1/4"	100	100
U03 05038??	1-1/2"	100	100
U03 05045??	1-3/4"	100	100
U03 05050??	2"	100	100
U03 05057??	2-1/4"	100	100
U03 05063??	2-1/2"	100	100
U03 05075??	3"	100	100
U03 05088??	3-1/2"	100	
U03 05100??	4"	100	
U03 05112??	4-1/2"	100	
U03 05125??	5"	100	
U03 05150??	6"	100	
Wrench size 5/32		Replace ?? With PL = Plain or ZP = Zinc	



1/4 Unf - 28 tpi

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U03 06006??	1/4	100	
U03 06010??	3/8	100	100
U03 06012??	1/2	100	100
U03 06016??	5/8	100	100
U03 06020??	3/4	100	100
U03 06022??	7/8	100	100
U03 06025??	1"	100	100
U03 06006??	1-1/8"	100	
U03 06032??	1-1/4"	100	100
U03 06038??	1-1/2"	100	100
U03 06045??	1-3/4"	100	100
U03 06050??	2"	100	100
U03 06057??	2-1/4"	100	100
U03 06063??	2-1/2"	100	100
U03 06069??	2-3/4"	100	
U03 06075??	3"	100	100
U03 06082??	3-1/4"	100	



Continued next page



Continued from previous page

Code	Length	Plain	Zinc
U03 06088??	3-1/2"	100	100
U03 06100??	4"	100	100
U03 06112??	4-1/2"	50	
U03 06125??	5"	50	
U03 06138??	5-1/2"	50	
U03 06150??	6"	50	
Wrench size 3/16		Replace ?? With PL = Plain or ZP = Zinc	

5/16 Unf - 24 tpi

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U03 08010??	3/8	100	
U03 08012??	1/2	100	100
U03 08016??	5/8	100	100
U03 08020??	3/4	100	100
U03 08022??	7/8	100	100
U03 08025??	1"	100	100
U03 08032??	1-1/4"	100	100
U03 08038??	1-1/2"	100	100
U03 08045??	1-3/4"	100	100
U03 08050??	2"	100	100
U03 08057??	2-1/4"	100	100
U03 08063??	2-1/2"	100	100
U03 08069??	2-3/4"	100	100
U03 08075??	3"	100	100
U03 08082??	3-1/4"	100	
U03 08088??	3-1/2"	100	100
U03 08100??	4"	100	100
U03 08112??	4-1/2"	50	50
U03 08125??	5"	50	
U03 08138??	5-1/2"	50	
U03 08150??	6"	50	
Wrench size 1/4		Replace ?? With PL = Plain or ZP = Zinc	

3/8 Unf - 24 tpi

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U03 10010??	3/8	100	
U03 10012??	1/2	100	100
U03 10016??	5/8	100	100
U03 10020??	3/4	100	100
U03 10022??	7/8	100	100
U03 10025??	1"	100	100



Continued next page



Continued from previous page

U03 10028??	1-1/8"	100	100
U03 10032??	1-1/4"	100	100
U03 10038??	1-1/2"	100	100
U03 10045??	1-3/4"	100	100
U03 10050??	2"	100	100
U03 10057??	2-1/4"	100	100
U03 10063??	2-1/2"	50	50
U03 10069??	2-3/4"	50	
U03 10075??	3"	50	50
U03 10082??	3-1/4"	50	
U03 10088??	3-1/2"	50	50
U03 10094??	3-3/4"	50	
U03 10100??	4"	50	50
U03 10106??	4-1/4"	50	
U03 10112??	4-1/2"	50	50
U03 10125??	5"	50	50
U03 10138??	5-1/2"	50	50
U03 10150??	6"	50	50

Wrench size 5/16

Replace ?? With PL = Plain or ZP = Zinc

7/16 Unf - 20 tpi

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U03 11012??	1/2	100	
U03 11016??	5/8	100	
U03 11020??	3/4	100	
U03 11022??	7/8	100	
U03 11025??	1"	100	100
U03 11032??	1-1/4"	100	100
U03 11038??	1-1/2"	100	100
U03 11045??	1-3/4"	100	100
U03 11050??	2"	50	50
U03 11057??	2-1/4"	50	50
U03 11063??	2-1/2"	50	50
U03 11075??	3"	50	50
U03 11088??	3-1/2"	50	
U03 11100??	4"	50	
U03 11125??	5"	50	
U03 11150??	6"	50	

Wrench size 3/8

Replace ?? With PL = Plain or ZP = Zinc





1/2 Unf - 20 tpi

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U03 12012??	1/2	50	
U03 12016??	5/8	50	
U03 12020??	3/4	50	50
U03 12022??	7/8	50	
U03 12025??	1"	50	50
U03 12028??	1-1/8"	50	
U03 12032??	1-1/4"	50	50
U03 12038??	1-1/2"	50	50
U03 12045??	1-3/4"	50	50
U03 12050??	2"	50	50
U03 12057??	2-1/4"	50	50
U03 12063??	2-1/2"	50	50
U03 12069??	2-3/4"	50	50
U03 12075??	3"	50	50
U03 12082??	3-1/4"	25	
U03 12088??	3-1/2"	25	25
U03 12094??	3-3/4"	25	
U03 12100??	4"	25	25
U03 12112??	4-1/2"	25	25
U03 12125??	5"	25	25
U03 12138??	5-1/2"	25	25
U03 12150??	6"	25	25
U03 12163??	6-1/2"	10	
U03 12175??	7"	10	
U03 12200??	8"	10	

Wrench size 3/8

Replace ?? With PL = Plain or ZP = Zinc

5/8 Unf - 18 tpi

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U03 16025??	1"	50	50
U03 16032??	1-1/4"	50	50
U03 16038??	1-1/2"	50	50
U03 16045??	1-3/4"	50	50
U03 16050??	2"	50	50
U03 16057??	2-1/4"	25	25
U03 16063??	2-1/2"	25	25
U03 16069??	2-3/4"	25	25
U03 16075??	3"	25	25
U03 16088??	3-1/2"	25	25
U03 16100??	4"	25	25



Continued next page



Continued from previous page

U03 16112??	4-1/2"	25	25
U03 16125??	5"	25	25
U03 16138??	5-1/2"	10	
U03 16150??	6"	10	10
U03 16163??	6-1/2"	10	
U03 16175??	7"	10	
U03 16200??	8"	10	

Wrench size 1/2


Replace ?? With PL = Plain or ZP = Zinc

3/4 Unf - 16 tpi

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U03 20025??	1"	25	
U03 20032??	1-1/4"	25	25
U03 20038??	1-1/2"	25	25
U03 20045??	1-3/4"	25	25
U03 20050??	2"	25	25
U03 20057??	2-1/4"	25	25
U03 20063??	2-1/2"	25	25
U03 20069??	2-3/4"	25	25
U03 20075??	3"	25	25
U03 20082??	3-1/4"	25	
U03 20088??	3-1/2"	25	25
U03 20100??	4"	25	25
U03 20112??	4-1/2"	25	25
U03 20125??	5"	25	10
U03 20138??	5-1/2"	10	
U03 20150??	6"	10	10
U03 20163??	6-1/2"	10	
U03 20175??	7"	10	
U03 20200??	8"	10	

Wrench size 5/8

Replace ?? With PL = Plain or ZP = Zinc



7/8 Unf - 14 tpi

Code	Length	Plain
Pack Quantity (if available)		
U03 22050PL	2"	10
U03 22057PL	2-1/4"	10
U03 22063PL	2-1/2"	10
U03 22069PL	2-3/4"	10
U03 22075PL	3"	10
U03 22082PL	3-1/4"	10
U03 22088PL	3-1/2"	10

Continued next page



Continued from previous page

U03 22100PL	4"	10
U03 22112PL	4-1/2"	10
U03 22125PL	5"	10
U03 22138PL	5-1/2"	10
U03 22150PL	6"	10
U03 22175PL	7"	10
U03 22200PL	8"	10

Wrench size 3/4

1" Unf - 14 tpi

Code	Length	Plain	Pack Quantity (if available)
U03 25050PL	2"	10	
U03 25057PL	2-1/4"	10	
U03 25063PL	2-1/2"	10	
U03 25069PL	2-3/4"	10	
U03 25075PL	3"	10	
U03 25082PL	3-1/4"	10	
U03 25088PL	3-1/2"	10	
U03 25094PL	3-3/4"	10	
U03 25100PL	4"	10	
U03 25112PL	4-1/2"	10	
U03 25125PL	5"	10	
U03 25138PL	5-1/2"	10	
U03 25150PL	6"	10	
U03 25175PL	7"	10	
U03 25200PL	8"	10	



Wrench size 3/4