



Button Head Socket Screw - UNF - Alloy Steel

#10 Unf - 32 tpi

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U30 05006??	1/4	100	100
U30 05008??	5/16	100	100
U30 05010??	3/8	100	100
U30 05012??	1/2	100	100
U30 05016??	5/8	100	100
U30 05020??	3/4	100	100
U30 05022??	7/8	100	100
U30 05025??	1"	100	100
U30 05032??	1-1/4"	100	100
U30 05038??	1-1/2"	100	100
U30 05045??	1-3/4"	100	100
U30 05050??	2"	100	100
U30 05057??	2-1/4"	100	
U30 05063??	2-1/2"	100	
Wrench size 1/8		Replace ?? With PL = Plain or ZP = Zinc	



1/4 Unf - 28 tpi

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U30 06006??	1/4	100	
U30 06008??	5/16	100	
U30 06010??	3/8	100	100
U30 06012??	1/2	100	100
U30 06016??	5/8	100	100
U30 06020??	3/4	100	100
U30 06022??	7/8	100	
U30 06025??	1"	100	100
U30 06032??	1-1/4"	100	100
U30 06038??	1-1/2"	100	
U30 06045??	1-3/4"	100	
U30 06050??	2"	100	
Wrench size 5/32		Replace ?? With PL = Plain or ZP = Zinc	



5/16 Unf - 24 tpi

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U30 08010??	3/8	100	
U30 08012??	1/2	100	100
U30 08016??	5/8	100	100
U30 08020??	3/4	100	100
U30 08022??	7/8	100	
U30 08025??	1"	100	100
U30 08032??	1-1/4"	100	100
U30 08038??	1-1/2"	100	100
U30 08045??	1-3/4"	100	
U30 08050??	2"	100	
Wrench size 3/16		Replace ?? With PL = Plain or ZP = Zinc	



3/8 Unf - 24 tpi

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U30 10012??	1/2	100	100
U30 10016??	5/8	100	100
U30 10020??	3/4	100	100
U30 10022??	7/8	100	
U30 10025??	1"	100	100
U30 10032??	1-1/4"	100	100
U30 10038??	1-1/2"	100	100
U30 10045??	1-3/4"	100	
U30 10050??	2"	100	
U30 10057??	2-1/4"	100	
U30 10063??	2-1/2"	50	
U30 10075??	3"	50	
Wrench size 7/32		Replace ?? With PL = Plain or ZP = Zinc	

1/2 Unf - 20 tpi

Code	Length	Plain	Zinc
Pack Quantity (if available)			
U30 12025??	1"	100	
U30 12032??	1-1/4"	100	100
U30 12038??	1-1/2"	100	100
U30 12050??	2"	50	50
U30 12063??	2-1/2"	50	
U30 12075??	3"	50	
U30 12100??	4"	25	
Wrench size 5/16		Replace ?? With PL = Plain or ZP = Zinc	